


1 Grind sample and weigh out 25g



2 Add EB17 pouch and 75 mL water




3 Cap, and shake vigorously to dissolve pouch



4 Place sample on a mechanical shaker on high for 1 minute




5 Filter the extract




6 Lay out items to run assay: DB5 buffer, strips, tubes, incubator, pipettes, and tips




7 Add 100 µL DB5 Buffer to each tube




8 Add 100 µL Sample Extract to each tube; stir each tube well to mix Buffer and Extract



9 Add strips to tubes for testing



10 Set timer for 4 minutes



11 Remove strips immediately after 4 minutes and cut off the arrow tape "tail pads"



12 Insert strips into carrier and press Read Test in the QuickScan main menu

